

Torque Air to Air (Inch-Pounds)

Model No.	Supply Pressure (psi)				
	40	60	80	100	120
A79P	69	103	137	172	208
B79P	101	147	202	257	308
B579P	204	290	396	496	535
C79P	285	418	576	730	867
C579P	475	691	929	1162	1367

Torque Air to Air (Inch-Pounds)

Model No.	Supply Pressure (psi)				
	40	60	80	100	120
D79P	665	979	1294	1698	2020
D579P	855	1654	2349	2988	3311
E79P	1859	2737	3618	4734	5641
F79P	3507	5063	6798	8974	10637
G79P	8797	12861	17098	22446	26696

Torque Air to Spring (Inch-Pounds)

Model	Spring	Supply Pressure (psi)											
		40 PSI		60 PSI		80 PSI		100 PSI		120 PSI		Spring Stroke	
		Set	Start	End	Start	End	Start	End	Start	End	Start	End	Start
A79PS	1	43	29	77	63	111	97	146	132	182	168	40	26
	2			65	45	99	79	134	114	170	150	58	38
	3			48	21	86	55	121	90	157	126	82	51
	4*					79	45	114	80	150	116	92	58
B79PS	1	59	39	105	85	160	140	215	195	266	246	62	42
	2			81	54	136	109	191	164	242	215	93	66
	3			56	31	111	86	166	141	217	192	116	91
	4*					102	61	157	116	208	167	141	100
B579PS	1	123	89	213	174	306	265	415	378	497	454	118	81
	2			167	112	257	199	371	319	445	382	179	125
	3			116	66	203	150	322	275	387	330	223	175
	4*					184	97	306	228	367	274	270	192
C79PS	1	170	120	303	253	461	411	615	565	752	702	165	115
	2			243	171	401	329	555	483	692	620	247	175
	3			165	60	323	218	477	372	614	509	358	253
	4*					290	163	444	317	581	454	413	286
C579PS	1	315	265	539	484	775	715	-	-	-	-	199	145
	2	232	149	447	354	676	576	957	869	-	-	326	235
	3			391	260	616	477	904	780	1136	1006	416	289
	4					556	378	851	665	1080	913	506	344
	5*					457	258	762	585	988	801	615	434
D79PS	1	426	290	746	593	1081	918	-	-	-	-	370	223
	2	313	87	619	364	945	674	1351	1109	-	-	593	346
	3			466	135	782	429	1206	891	1533	1202	816	494
	4*				-	701	320	1132	794	1457	1100	915	569
D579PS	1	931	849	1501	1409	2118	1991	-	-	-	-	313	224
	2	562	234	1087	719	1646	1254	2336	1985	-	-	984	627
	3			788	294	1326	799	2050	1580	2646	2152	1397	917
	4*			-	-	1183	607	1922	1408	2511	1972	1572	1048
E79PS	1	1391	1075	2301	1945	3244	2864	-	-	-	-	831	484
	2	1075	631	1945	1447	2864	2331	3959	3484	-	-	1315	831
	3	695	188	1518	948	2407	1799	3552	3009	4469	3899	1799	1246
	4*	-	-	1162	307	2027	1115	3212	2202	4112	3257	2422	1592
F79PS	1	3285	2488	5507	4612	7817	6861	-	-	-	-	2437	1566
	2	2170	1055	4253	3000	6478	5140	9235	8041	-	-	4003	2785
	3	-	-	3179	1388	5331	3418	8212	6505	10443	8650	5569	3829
	4*	-	-	-	-	4757	2080	7700	5311	9905	7395	6787	4351
G79PS	1	6968	6131	11081	10140	15299	14294	-	-	-	-	2135	1220
	2	5852	4456	9826	8257	13958	12283	18638	17144	-	-	3964	2440
	3	4456	2502	8257	6060	12283	9937	17144	15051	21261	19063	6099	3964
	4	-	-	7002	3236	10943	6921	15948	12360	20005	16236	8843	5184
	5*	-	-			9267	4241	14453	9969	18434	13723	11283	6709

* Standard Spring Set

Caution: Springs under tension. Only factory or authorized personnel may safely replace springs using special tools and equipment